




installationsvejledning


Flair Enthalpy Varmveksler
Dansk




Air for Life

Montering Flair Enthalpy Varmeveksler


1





2





3



4




5





6

Placer entalpe varmeveksleren i apparatet.




1 = Enthalpy varmeveksler
Artikelkode: 532710


7



- 8** A = Fjern kondensatafløb.
B = Luk kondensatafløb med den medfølgende låg.



9





Brink Climate Systems BV
P.O. Box 11 NL-7950AA Staphorst
T +31 (0) 522 46 99 44

E info@brinkclimatesystems.com
www.brinkclimatesystems.com
www.brinkairforlife.com